



SAFETY SYSTEMS

FIRST TIME SETUP GUIDE

G-ON4 Dash Camera






CONGRATULATIONS

G-ON4 Dash Camera

Congratulations on the purchase of your new G-ON4 Dash Camera. This document is designed to help you set up and use this device with ease. Keep this in the car or a safe spot, for easy reference if required.

Take a quick look over the diagrams below to get a better understanding of managing video files from the Dash Camera.



Please ensure your dash camera is plugged in to be operational.

FOR SUPPORT CALL 1800 818 288

HOW TO REMOVE THE SD CARD:

- First, unplug the power cord to turn off the dashcam. (SEE ABOVE DIAGRAM)
- Then open the cover of the microSD card slot. (SEE DIAGRAM A)
- To remove the microSD card: gently press on the card to release the lock, then carefully pull the card out. (SEE DIAGRAM B)
- To insert the microSD card, gently push the card into the slot (in correct orientation) until it locks into place and close the cover. (SEE DIAGRAM C)

DIAGRAM A



DIAGRAM B





DIAGRAM C



PLAYING AND MANAGING VIDEO FILES USING YOUR COMPUTER:

- You can use a microSD card reader (not included) to view your footage on a compatible computer.
- You'll find on the MicroSD card the GNET App.
- Install this App onto your computer for the best viewing experience.





QUICK START GUIDE

For connecting a G-ON4 Dash Camera via the GNET App with Android device.

ANDROID INSTRUCTIONS

STEP 1

Search and download the GNET App from the Play Store.




STEP 2

Once installed, ensure the vehicle ignition is 'on' and have your engine running whilst proceeding this setup.


STEP 3

Press the Wi-Fi button on the G-ON4 camera. You will hear a voice notification "standby for the registration of device".



STEP 4


Click on the "+" icon in the top right corner to register your G-ON4 camera to your app. Your phone will now begin to search for your G-ON4 camera automatically. Once found, press "Connection" at the bottom of your phone's screen.



STEP 5

Your phone will now automatically connect to your dash camera. You may see a pop up asking to "connect to device". Click 'connect'.

Once connection is complete, you can access, save or send footage and personalise the settings.



TROUBLESHOOTING:

If you are unable to connect with the auto Wi-Fi connection within the app, go into the phone settings then connect to the **GNET_BB_GON4_XXXXXX** Wi-Fi manually using password: **qwertyuiop**

- If you are having trouble connecting to the app, first check your location settings are enabled and then try re-starting the phone.

IMPORTANT NOTES:

If the SD card needs to be removed from or reinserted into the device, ensure dash camera is powered off first.

- Most essential settings are pre-set prior to, or during installation such as time zone and low voltage cut-off. Please do not change the camera settings. Refer to the installer for details.
- Your G-ON4 dash camera will provide you with the following voice notifications:

VOICE NOTIFICATION	EXPLANATION
Records in parking mode.	Key off – camera will begin parking mode.
Driving mode to start recording. Safe driving.	Key on – camera will begin driving mode.
Impact occurred during parking.	Impact has been sensed during parking mode. This could be an impact to the vehicle or from the vehicle's door being closed.
System shut down to protect the battery.	Car parked. Camera will automatically turn off after voltage drops below set value.

Please refer to your User Manual for more in depth information.

FOR FURTHER SUPPORT CALL 1800 818 288





QUICK START GUIDE

For connecting a G-ON4 Dash Camera via the GNET App with iPhone or iPad.

INSTRUCTIONS

STEP 1

Search and download the GNET App from the App Store.




STEP 2

Once installed, close the app store. Now ensure the vehicle ignition is 'on' and have your engine running whilst proceeding with this setup.


STEP 3

Navigate to the phone settings and turn on Wi-Fi. In the Wi-Fi list, select the name that starts with **GNET_BB_GON4_XXXXXX**. Enter password: **qwertyuiop**



STEP 4

Press the Wi-Fi button on the G-ON4 camera. You will hear a voice notification: "standby for the registration of device".




STEP 5

Open the GNET App on your iOS device and the device will automatically connect to the dash camera. Once connected, you can access, save or send footage.

STEP 6

If this message pops up on your phone's screen, select 'Keep Trying Wi-Fi'.



TROUBLESHOOTING:

- If you are having trouble connecting to the app, first check that your location settings are enabled and then try re-starting the phone.

IMPORTANT NOTES:

If the SD card needs to be removed from or reinserted into the device, ensure dash camera is powered off first.

- Some essential settings are pre-set prior to, or during installation such as time zone and low voltage cut-off. Please refer to your reseller for details.
- Your G-ON4 dash camera will provide you with the following voice notifications:

VOICE NOTIFICATION	EXPLANATION
Records in parking mode.	Key off – camera will begin parking mode.
Driving mode to start recording. Safe driving.	Key on – camera will begin driving mode.
Impact occurred during parking.	Impact has been sensed during parking mode. This could be an impact to the vehicle or from the vehicle's door being closed.
System shut down to protect the battery.	Car parked. Camera will automatically turn off after voltage drops below set value.

Please refer to your User Manual for more in depth information.

FOR FURTHER SUPPORT CALL 1800 818 288